

SLOWSTOP® BOLLARDS BASIC INSTALLATION INSTRUCTIONS














































SLOWSTOP® BOLLARDS **DETAILED INSTALLATION INSTRUCTIONS**







Materials

Tools Required 1—Base Hammer Drill

1—Elastomer Drill Bit sized for Anchor

Impact Wrench 1—Adapter with Set-Screws 1—Tube Impact Socket

1—Cap Vacuum or Compressed Air with Nozzle

4 to 8—Screw Anchors Depending on Model 6mm / 8mm Allen Wrench

Mallet

Notes

- 1. Assembly and installation should be performed by qualified personnel only.
- Installation to be performed in unbroken concrete only. Anchor holes should be 5x the diameter of the anchor from any edge.
- Bollards must be properly sized for expected loads and speeds. Consult www.slowstop.com.
- Study Figure 1 to understand the arrangement of all parts.
- Pipe used must be as specified by SlowStop.

Installation and Assembly

- 1. Layout and mark final location using the base as a guide. Remove base. Note: Keep the bollard 0.32 x height away from any solid object to allow for tilting.
- 2. Place the elastomer in the center of the location and place adapter on top of elastomer.
- Fit base over the adapter so that it rests on the adapter flange and covers the elastomer.
- 4. Again using the base as a guide, drill four, six, or eight (as required) holes deep enough to completely sink the anchors. Clean out the holes from concrete dust.
- 5. Tighten the concrete screw Anchors in a star pattern, compressing the elastomer and making the base flush to the concrete. Anchor head must be tightened flush to base.
- Insert the tube into the adapter and firmly tighten all set-screws to hold it in place.
- Place the cap in the top of the tube and gently pound it in place using a mallet.
- When complete, the assembly should appear like Figure 2.

Tip: Do not concrete fill the bollard. The system is designed for the pipe to be the first point of bending



Figure 2

WWW.POSTGUARD.COM (866) 737-8900